Drum Synthesizer/Sequencer


Voice Volume

Voice Decay

Voice Pitch Sample Select

Toggle Step Sample Record Mode: Select Sample Slot Menu Mode: Play/Stop, Select Sync Mode, Save/Load Sequences

Top LED Row Green: Kick Pink: Snare Teal: High Hat Yellow: Tom Blue: Sample **Bottom LED Row** Shows Active Steps



USB Power + MIDI Clock Input

- Coloction

Audio / Pulse

Playing: Toggle Record Automation Stopped: Toggle Sample Record Mode Input Output Long Hold: Clear Everything

> Start / Stop Sequence Long Hold: Toggle Menu

Voice Select Sample Mode: